



CAUTION!

Before connecting rebuilt cylinders to old hoses:

- 1) Empty pump reservoir of all old oil.
- 2) Fill pump reservoir with clean oil, and with hoses disconnected from Cylinders place ends of hoses in bucket or pan & run pump until you see new oil at ends of hoses, this flushes all the contamination out.
- 3) Install rebuilt cylinders on lift
- 4) Connect hoses to cylinders, add nitrogen to schrader valves on cylinders, we recommend 50PSI left & 70 PSI right with lift all the way down.
- 4) Cycle lift up and down 2 or 3 times, this should bleed out all air from the system
- 5) With lift all the way down add oil to reservoir to normal level